
Wi-Fi & 4K CONSTRUCTION TIME LAPSE CAMERA BCC5000



User Manual



Contents


In the Box	5
Device Parts	7
LED Indicators	10
Initial Setup	12
Charge Before Use	13
Camera 📋 Installing Battery Pack	14
Camera \mid MicroSD Card & Lens Hood	15
Housing Installing Battery Pack	16
Housing Installing Camera	17
Housing \mid Locking the Door	18
Clamp Install Release Adapter	19
Operating Methods	27
Bluetooth Operation	30
Bluetooth 📔 Home Page	31
Bluetooth Camera Connect	32
Bluetooth Camera Status	33
Bluetooth Camera Settings	34
Bluetooth $ $ Take a Photo (adjust camera view angle)	35
Bluetooth $ $ Schedule Setting (daily & weekly recording schedule)	36
Bluetooth Time Interval	37

Bluetooth How to Start a Time Lapse Recording	38
Bluetooth How to Check Camera Status During Recording	39
Bluetooth Add Camera to Your Account4	10
Bluetooth Sign up/login Your Account4	11
Bluetooth Set Camera Wi-Fi4	12
Bluetooth Register Camera4	13
Bluetooth Register Completed4	14
Wi-Fi Operation4	16
Wi-Fi Initial Page4	17
Wi-Fi Camera ID4	18
Wi-Fi Live View4	19
Wi-Fi Start/Stop Recording5	50
Wi-Fi Settings & Info5	51
Settings Schedule5	52
Settings Time Interval5	53
Settings Configure Settings5	54
Settings Battery Details5	55
Settings SD Card5	56
Settings About Camera5	57
On-Camera Operation5	59

In the Box


1. 4K Time Lapse Camera – TLC5000

- 1.1. Camera
- 1.2. Lens hood
- 1.3. USB-C cable
 - 1.4. MicroSD card with adapter



 \bigcirc


2. Construction Power Housing – ATH5000



- 2.1. Camera protective housing
- 2.2. Extra battery slot
- 2.3. Camera mounting adapter (pre-install in the camera protective housing)

In the Box

3. Camera Clamp Pro - ACC5000



4. Battery Pack – MRB1000



4.1. Rechargeable battery pack x2

3.1. Camera clamp3.2. Extension poles

3.4. Quick release adapter

3.3. Magic arm

3.5. Screws

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

Device Parts

1. Camera





FRONT

- 1.1. Spirit level
- 1.2. Lens
- 1.3. Start/stop button with LED indicator
- 1.4. Time interval button
- 1.5. Tripod mount (size: ¹/₄")
- 1.6. **SIDE**
- 1.7. Power switch
- 1.8. MicroSD card slot
- 1.9. USB-C socket
 - Charging battery (need to turn on camera power)
 - Power supply



BACK 1.10.Battery cover 1.11.Cover lock Battery slot

Device Parts

2. Construction Power Housing



FRONT SIDE

FRONT SIDE

- 2.1. Extra battery slot x3
- 2.2. Battery lock
- 2.3. Power-in port (for solar power) (USB-C)
- 2.4. Data transfer port
- 2.5. Door & latch



BACK SIDE

- 2.6. Camera mount adapter
- 2.7. External power connector (USB-C)
- 2.8. Door & latch
- 2.9. Tripod mount (size: ¹/₄")

BACK SIDE


Device Parts

3. Camera Clamp Pro



Magic Arm

- 3.1. Quick release adapter (for camera)
- 3.2. Flex arm knob
- 3.3. Clamp mount



Camera Clamp

- 4.1. Clamp head
- 4.2. Extension pole hole knob
- 4.3. Clamp head knob
- 4.4. Mounting hole (1/4") (x3)
- 4.5. Handle

LED Indicators

1. Camera



1.1 Power/recording status

GREEN
 Solid: Power on
 Blinking: Recording

• RED Solid: No SD card, Blinking: Low battery, low MicroSD card storage

1.2 Time interval

• GREEN Solid: Indicated current time interval setting


1.3 Connection status

BLUE

Solid: Camera connected to camera server Blinking: Wi-Fi connecting

LED Indicators

2. Construction Power Housing (Battery Slot)



When battery pack inserted:

LED lights on: standby

- Green: Battery capacity > 15%
- Red: Battery capacity <15%

(recommended to charge battery pack)

LED blinking: Battery pack is currently powering the camera.

LED lights-off:


- Remaining battery capacity too low.
- Battery error.

Please remove the battery pack and charge through an external DC adapter.


Initial Setup

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

Charge Before Use




Camera | Installing Battery Pack



- 1. Unlock the battery cover.
- 2. Remove the battery cover.
- 3. Install battery pack.
- 4. Close the battery cover.
- 5. Lock the battery cover.

Camera | MicroSD Card & Lens Hood


6



Open the microSD card cover


- 6. Insert lens hood.
- 7. Insert microSD card.
- 8. Turn on camera.


Housing | Installing Battery Pack



2

3






Open Battery slot cover

- 1. Insert the battery pack included in the package*.
- 2. Green LED lights on meaning the battery pack is installed correctly.
- 3. Lock the battery pack with battery lock.

Note:

- **1.** Fully charged before use.
- 2. Supports up to 3 battery packs in total.

Housing | Installing Camera



Open CAMERA HOUSING cover

- 4. Remove the camera mounting adapter.
- 5. Secure the camera and the adapter with the screw.
- 6. Open the USB-C cover on the camera, and plug the external power connector into the camera.

Then, insert the adapter with the camera attached back into the camera housing.

Housing | Locking the Door






8. Lock the latches, and a "click" sound means correctly installed.




Clamp | Install Release Adapter




- 1. Remove the Quick Release adapter from the Magic Arm.
- 2. Install the Quick Release adapter to the Construction Power Housing with the big screw and two other small screws.

Clamp | Assemble Magic Arm




3. Install Magic Arm on the Camera Clamp

Clamp | Assemble




- 1. Attach Camera Clamp to a desired location, tightening the handle.
- 2. Adjust Magic Arm to a desired position.


Clamp | Assemble Housing to Clamp



- 1. Loose the locking switch.
- 2. Slide the Quick Release adapter at a tilted angle to secure it.
- 3. Lock the switch.




Clamp | Find Your Desired Position




1. Adjust the whole set to find your desired position


Clamp | Install Extension Pole



Clamp | Install Extension Pole



Clamp | Install Extension Pole




Operating Methods

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

3 Operating Methods

The camera (TLC5000) can be operated through the following methods:






3. On-Camera operation

- Select desired time interval.
- Start/stop recording.

Bluetooth Operation

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

Bluetooth Operation



Turn on the camera.



Using Google Chrome to access the following web app on your laptop or desktop*.


Bluetooth app (CLICK HERE)

Note: Make sure Bluetooth function on your laptop or desktop is enabled.

Requirements:


- Laptop or desktop with Bluetooth function
- Operating system: Windows or macOS
- Web browser: Google Chrome
- Connecting range: Within 10 meters.

Bluetooth | Home Page




Wi-Fi & 4K Construction Time Lapse Camera BCC5000


Bluetooth Camera Connect



Bluetooth Camera Status



Bluetooth | Camera Settings



2. Start Recording

Start/stop recording with Bluetooth app.

3. Schedule Setting

Set daily & weekly capture schedule.

- **4. Time Interval** Set time interval.
- **5. Camera Wi-Fi** Setup Wi-Fi connection to the camera for remote control.


Bluetooth | Take a Photo (adjust camera view angle)

Conner 10 Do26-0001-5002-3432-3052-2034 Take a Photo Mat any execution to Start Recording Schedule Time Interval Canera Wi-fi © Canera Wi-fi ©	1. Click Take a Photo. Camera instantly captures the present frame and sends to Bluetooth app.
photo x	 2. Check camera view angle. Adjust camera view angle, and click <i>Reload</i> to receive updated frame. Note: Take a Photo is unavailable when the camera is recording

Bluetooth | Schedule Setting (daily & weekly recording schedule)

Camera D' DO26 00051 S002-9432 3052 0034	1. Click Schedule.
Camera ID 005E-004F-5012-3232-314D-2032 Schedule 01 hr 01 hr 00 ml 3 5 top recording at 10 hr 00 ml 4 5 Recording File Across Days Cancel Save 7	 Enable/disable Schedule. Select Start Recording Time Decide Start Recording Time Schedule Days Select desired recording days of week. File Split Continuous: Camera will automatically combine several days of recording into a single file. Daily: Every daily recording produces a single daily video file. *File exceeding 500mb will be split into multiple files. Click Save to save settings

Bluetooth | Time Interval



Bluetooth | How to Start a Time Lapse Recording

Camera ID 0026-0051-5002-3432-3052-2034	
Take a Photo Must stop recording first	
Start Recording	D 1
Schedule 4	
Time Interval	2 🖉
Camera Wi-fi	7
About Firmware Version: 0.5036.0 / 0.94.0 / 0.1.13271 Timezone: UTC+8 App Version: 0.2.4396	
1. Take a photo to confirm camera view angle. 2. Set daily & weekly recording schedule.	
3. Set desired time interval.	
4 Start your time lapse recording.	
Note:	
To access the recorded video file, visit the Wi-Fi Operating A	App for download.

Bluetooth How to Check Camera Status During Recording

	Go to <u>Bluetooth app (CLICK HERE)</u>
<complex-block> Image: control of the co</complex-block>	 Click <i>Camera Connect</i>. Find the camera with the unique Bluetooth ID. Click <i>Pair</i> button.
Camera ID 0026-0051-5002-3432-3052-2034 Now Recording 1 74.% Battery Health Camera Settings Camera Settings Register Camera This camera is not registered to any account	At Camera Status page 1. Indicate the camera is recording. 2. Check battery & SD card capacity

Bluetooth Add Camera to Your Account


Adding a camera to your account means you can remote control all your cameras, it will require two steps:

Step 1. Sign up/login to your account.

Step 2. Setup Wi-Fi connection to the camera.

Note:

At this process, your laptop/desktop & camera need to connect to a stable Wi-Fi.



Bluetooth | Sign up/login Your Account

Email Address Password Crigot Password? Login Don't have an account? Sign up	 Login: If you already have an account. Sign up: Create a new account.
Log out Cog ou	3. After completed account login/sign up, return to register camera page.

Bluetooth | Set Camera Wi-Fi

÷	At Register Camera Page
Camera ID 0026-0051-5002-3432-3052-2034 Register Camera Please connect your camera to WiFi to continue with registration Please set up WiFi first. If already set, give the camera a moment to connect.	1. Click Setup Wi-Fi.
Camera UP D026-0051-5002-3432-3052-2034 Camera WI-FI Drinno Camera Deter your SSID Deter your password Deter your password Det	 Enter your Wi-Fi name (SSID) & password. Note: Please ensure your Wi-Fi supports 2.4 GHz or Dual (2.4/ 5 GHz) frequency bands. Select Remember my account. Click Save to save settings.
	The Blue LED blinks while connecting to Wi-Fi, and turns solid when the connection completes.

Bluetooth | Register Camera

\	While camera is connected to Wi-Fi
Camera ID 0026-0051-5002-3432-3052-2034	1. Click Register.
Register Camera	
After camera registration, you can watch live view on the Multi-Camera System.	
Cancel	
	2. Camera Registered.
← ⊂ Camera ID (Registered)	
0026-0051-5002-3432-3052-2034	
Register Camera	
Camera Registered	
You can access the camera via WIFI on the <u>Multi-Camera System</u>	
ок 2	


Bluetooth | Register Completed

brinno			ф <mark>2</mark>
	Camera ID (Registered) 0026-0051-5002-3432-3052-2034		
	📑 Not R	ecording	
	75%	4%	
	Battery Health	SD Card Status	
	Camera	Settings	
	Multi-Came	era System	
	Unregiste	r Camera	(2)
	This camera is registere	d to user@brinno.com	
Log info Rx 29: Reg or		14358 J	
i da batala	na sanc succes of search and solution of solutions is even in a	ner //ware aalse, forage al, saaronu na je kojjj	
Once the camera is registe	ered, you can use t	ne following function	S:
1. Multi-Camera System			
Remote control all your	registered cameras	s through Brinno cloud	d platform.
2. Unregister Camera			
Remove the registered	camera from your a	account.	


Wi-Fi Operation

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

Wi-Fi Operation




Wi-Fi | Initial Page




Wi-Fi | Camera ID

Camera ID Doce-odoct-stod2-add2-add2-add2-add2-add2-add2-add2-a	1. Camera ID Each camera has a unique Camera ID, which can also be found on the label included in the package.
Camera ID © 0026-0051-5002-3432-3052-2034 Image: Comparison of the second	 2. Connection Status If the Disconnected Sicon appears next to the Camera ID, it means the camera's Wi-Fi connection is disconnected. Please wait a few seconds and try logging into the Wi-Fi Operation web app again. If the issue persists, check the camera and Wi-Fi signal for possible problems. 3. Disconnection When disconnected, Live View and Start Recording functions will be unavailable.


Wi-Fi | Live View




Wi-Fi | Start/Stop Recording




Wi-Fi | Settings & Info



Settings Schedule




Settings | Time Interval



Settings | Configure Settings

Camera ID 0026-0051-5002-3432-3052-2034 Schedule Time Interval Configure Settings	1. Click Configure Setting.
	2. Optionally preview the image in Live
← ♀	View for advanced adjustments.
Camera ID 0026-0051-5002-3432-3052-2034	3. Flicker Filter
Configure Settings	Off: Recommended for outdoor use.
	50 Hz : Europe, Africa, South East Asia,
	China, Australia and East Japan.
Preview in Live	60 Hz : America, Taiwan, Korea,
2	Philippines, West Japan.
	Note: Please set your preferred flicker filter for
Flicker Filter	indoor recording.
Off 50Hz 60Hz	4. Time Stamp
Time Stamp	Enable/disable time stamp.
Advanced Settings	5. Advanced Settings
5	Sharpness, saturation, and playback rate
	settings.

Settings Battery Details



Settings SD Card

Battery Detail SD Card About Camera Help	1. Click SD Card.
Camera ID D026-0051-5002-3432-3052-2034 SD Card Reload NAME ^ April 28, 2025 Reload 11C00001-MP2 April 28, 2025 808935296 11C00001-MP2 April 28, 2025 808935296 11C00001-MP2 April 28, 2025 808935296 11C00001-MP2 April 28, 2025 120001-MP2 120001-MP2 120001-MP2 12001-MP2 12001-MP2 12001-MP2 12001-MP2 1201-P2 1201-P2	 Click <i>Reload</i> to refresh and display the latest stored videos. Click a <i>file name</i> to begin playback.
	4. Video playback page to view the selected recording.

Settings About Camera

Battery Detail SD Card About Camera Help	1	1. Click About Camera.
	企 (2)	2. Firmware upgrade.
	රිකmera ID 5002-3432-3052-2034	
Camera ID	0026-0051-5002-3432- 3052-2034	
PWA	0.2.4628	
Hardware	0.5036.0	
Firmware	0.94.0	
WiFi	0.1.13271	
	nware is available. IRMWARE TO 13428	

On-Camera Operation

Wi-Fi & 4K Construction Time Lapse Camera BCC5000

On-Camera Operation

ON OFF	Turn on the camera.
	 Start Recording Select the desired time interval by pressing <i>Time Interval</i> button. Position the camera as needed. (Tip: Use the spirit level.) Press and hold the <i>Start/Stop</i> button for 2 seconds. The Interval LED will light up and begin blinking. How can I know if the camera is recording? During Recording, the start/stop button LED blinks once every 8 secs. Pressing the <i>Start/Stop</i> or <i>Time Interval</i> button will make the selected interval LED light up briefly. Stop Recording Press and hold the <i>Start/Stop</i> button for 3 seconds. The Interval LED will light up and the <i>Start/Stop</i> button LED will light up and the <i>Start/Stop</i> button LED will blink for several seconds.

