

## Motion Activated Camera MAC100

version EN A1

# Firmware Upgrade Procedure


Please follow below steps to upgrade your Brinno Motion Activated Camera:

**Step 1** Ensure your Motion Activated Camera is powered down and remove SD card from the camera. Then insert the SD card into your computer.




**Step 2** Copy and save the file:  
**fw\_MAC100\_20120201\_24.ldr** into **100MAC** folder in the SD card (100MAC folder should locate in the **DCIM** folder)

**\*\* If your SD card doesn't have a folder named 100MAC in the DCIM folder, please create those folders by yourself!**




**Step 3** Insert the SD card into the Motion Activated Camera.

**Step 4** Power on the Motion Activated Camera.



**Step 5** After the upgrade tool has fully loaded, you will see Green, Red and Blue led lights flash, it means that the camera is updating firmware. **Please do not power off camera once led lights begin flashing!**



**DO NOT TURN OFF**

**Done** Once the led lights stop flashing and turn off, the firmware update is completed the upgrade.  
**\*\* The firmware will be removed automatically once the update is completed.**



Please **DO NOT** push the power button/ turn off camera or open camera once the lights begin flashing.

## That will damage the camera!

Supports: [customerservice@brinno.com](mailto:customerservice@brinno.com)

[www.brinno.com](http://www.brinno.com)

2013.09.16